

Installation Manual

Model No.: HG-L208T-22


LED TROFFER


CCT AND WATT CHANGING





WATT CHANGING: 25W/30W /40W






CCT CHANGING: 3000K/3500K/4000K/5000K

Installation manual

A.T-Grid ceilings installation


Step1



Turn off the switch

Step2


Remove the ceiling (s) at an appropriate location where the light fixture is to be installed.




Step3

Power Leads Connection Remove screw holding access cover plate and remove the necessary knockout

Knockout




Step4



Connect cable wires with appropriate relief strain and wire connectors(ont provided). Make sure ALL wires are tucked in before reinstalling the cover plate.

Wiring Diagram



Step5

